

Flow-Alert™ Flow Switch Installation & Maintenance Instructions

HEDLAND®
DIVISION OF RACINE FEDERATED INC.

FORM #HLIT 290

8635 Washington Avenue • Racine • Wisconsin 53406-3738
TEL 1-800-HEDLAND • FAX 1-800-CHK-FLOW

⚠ CAUTION

This product should be installed and serviced by technically qualified personnel trained in maintaining industrial class flow instrumentation and processing equipment.

⚠ CAUTION

Read instructions thoroughly before installing the unit. If you have any questions regarding product installation or maintenance, call your local supplier for more information.

I. INTRODUCTION

The FLOW-ALERT™ flow meter combines the rugged proven technology of a direct reading, piston-type, variable area flow meter, coupled with electrical contacts utilized to signal at selected flow rates. This combination is sealed against industrial contamination by a NEMA 12 and 13 (IP52/54) rated enclosure.

This product provides a local flow indication and automatically signals the operator or PLC if flow is too high or too low.

Uses of the FLOW-ALERT™ flow meter include: bearing lubrication, case drain verification, gun drill cooling, pump flow confirmation, etc.

II. SPECIFICATIONS

Enclosure Rating

- NEMA 12 & 13 (equivalent to IP 52 & 54)

Temperature Range

- -20 °F to 240 °F (-20 °C to 116 °C)

Pressure Rating Aluminum/ Brass

- Liquids (1/4" to 1-1/2"): 3500 psi (241 bar) maximum, with a 3:1 safety factor
- Gases (1/4" to 1-1/2"): 1000 psi (69 bar) maximum, with a 10:1 safety factor

Pressure Rating Stainless Steel

- Liquids (1/4" to 1/2"): 6000 psi (414 bar) maximum, with a 3:1 safety factor
- Liquids (3/4" to 1-1/2"): 5000 psi (345 bar) maximum, with a 3:1 safety factor
- Gases (1/4" to 1-1/2"): 1500 psi (103 bar) maximum, with a 10:1 safety factor




Figure 1. FLOW-ALERT™ Flow Meter

Accuracy

- $\pm 2\%$ of full scale

Repeatability

- $\pm 1\%$

Pressure Drop

- See Appendix for specific meter information

Micro Switch

- Single (1) or double (2) switch, prewired single-pole, double-throw (SPDT), UL recognized and CSA certified switch
- Type: SPDT
- Contact Rating VAC: 250 Volt, 10 Amp
- Contact Rating VDC: 125 Volt, 0.5 Amp
- Cable Single Switch: 34", 4-wire, #18 AWG, SO jacket
- Cable Dual Switch: 18", 7-wire, #16 AWG, SO jacket

Reed Switch

- Single (1) or double (2) reed switch, prewired single-pole, single-throw normally open (SPST-NO); or single-pole, single-throw normally closed (SPST-NC); UL recognized and CSA certified switch
- Type: SPST
- Contact Rating (maximum see Figure 2): Normally Open 10 Watts, Normally Closed 5 Watts
- Voltage (maximum at switching): Normally Open 50 VDC, Normally Closed 50 VDC
- Current (maximum amps at switching, resistive load): Normally Open 0.5 Amp, Normally Closed 0.5 Amps
- Initial Contact Resistance: 0.100 Ohms
- Cable: 15' (4.6 m), 4-wire, #22 AWG, PVC jacket

Double Break Switch

- Single (1) switch, prewired, UL recognized and CSA certified switch
- Type: Double Break
- Contact Rating VAC: 125/250 Volt, 10 Amp
- Contact Rating VDC: 28 Volt, 6 Amp





Figure 2. Reed Switch Power Dissipation

Dimensions

A Nominal Port Size	B Length in. (mm)	C Length in. (mm)	D Length in. (mm)	E Width in. (mm)	F Width in. (mm)	G Width in. (mm)	H Width in. (mm)	I Depth in. (mm)	J Offset in. (mm)	K Hole Dia. in. (mm)
1/4 (SAE 6)	6.60 (168)	5.27 (134)	6.41 (163)	6.00 (152)	3.23 (82)	3.00 (76)	4.20 (107)	2.94 (75)	1.51 (38)	.31 (8)
1/2 (SAE 10)	6.60 (168)	5.27 (134)	6.41 (163)	6.00 (152)	3.23 (82)	3.00 (76)	4.20 (107)	2.94 (75)	1.51 (38)	.31 (8)
3/4 (SAE 12)	7.20 (183)	5.27 (134)	7.04 (179)	6.00 (152)	3.60 (91)	3.00 (76)	4.20 (107)	2.94 (75)	1.27 (32)	.31 (8)
1 (SAE 16)	7.20 (183)	5.27 (134)	7.04 (179)	6.00 (152)	3.60 (91)	3.00 (76)	4.20 (107)	2.94 (75)	1.27 (32)	.31 (8)
1-1/4 (SAE 20)	12.20 (310)	10.68 (271)	11.65 (296)	7.63 (194)	4.84 (123)	3.82 (97)	5.02 (128)	4.50 (114)	2.20 (56)	.31 (8)
1-1/2 (SAE 24)	12.20 (310)	10.68 (271)	11.65 (296)	7.63 (194)	4.84 (123)	3.82 (97)	5.02 (128)	4.50 (114)	2.20 (56)	.31 (8)



III. INSTALLATION

This unit should be installed and serviced by technically qualified personnel trained in maintaining industrial class flow instrumentation and processing equipment.

⚠ CAUTION

This meter may contain residual amounts of test fluid at the time of shipment. This fluid should be removed prior to installation as the fluid may be incompatible or hazardous with some liquids or gases. Failure to follow these instructions could result in damage to the equipment.

⚠ CAUTION

This standard meter is unidirectional. Attempts to flow fluids in the opposite direction of the flow arrow will result in the meter acting as a check valve, creating a deadheading situation. If the differential pressure magnitude is great enough, damage to the internal parts of the meter will result.

⚠ WARNING

Disconnect electrical power before opening wiring enclosure. Failure to follow these instructions could result in serious personal injury or death and/or damage to the equipment.

⚠ WARNING

All wiring should be installed in accordance with the National Electrical Code and must conform to any applicable state and local codes. Failure to follow these instructions could result in serious personal injury or death and/or damage to the equipment.

⚠ CAUTION

Air/gas meters are NOT oxygen cleaned. Use with oxygen may cause hazardous or explosive conditions that may cause serious personal injury and/or equipment damage.

Installation Recommendations

The in-line flow meter is a simple device to install. However, the following measures are recommended for reliable, trouble-free operation:

Do - Align pipe accurately. Piping should be accurately aligned and of correct length. The high pressure body of the flow meter can withstand shock and flow/pressure pulsation. However, the piping should be firmly supported by external mounting brackets, both upstream and downstream of the meter, to avoid any pipe flexing action that could reduce meter life.

Do - Use rigid mounting. If the flow meter inlet or outlet are to be rigidly mounted, and the opposing port is to be connected to flexible hose, the end connected with the flexible hose must be rigidly mounted.

Do - Use Teflon® tape for sealing NPT fittings.

Do - Install unions. Install a union near the inlet or outlet of the meter. This will facilitate quick, easy meter removal and inspection during periodic maintenance procedures.

Do - Mount the meter either horizontally or vertically (flow arrow pointing to either side or straight up). If the meter must be mounted inverted, special inverted scales are available from the factory.

Do - Ensure the fluid is traveling in the direction of the flow arrow (Figure 3 on page 4).

Do - Use at least a 200 mesh (74 micron) filter. The meter will allow particulate to pass that would jam most valves and flow controls. Systems that do not have filtration should be equipped with at least a 200 mesh (74 micron) filter. Most hydraulic systems already have much finer filtration.

Dirt, ferrous metal or sealing agents, such as Teflon® tape may lodge and cause malfunction. If the meter is jammed at a fixed position, follow cleaning and maintenance instructions.

Don't - Use thread locking compounds as thread sealant.

Don't - Install the flow meter near turbulence producing fittings such as elbows, reducers, close coupled valves, etc. The in-line flow meter does not require flow straighteners or special lengths of straight inlet/outlet piping to stabilize turbulent flow patterns. However, to assure maximum operational reliability, avoid installation of elbows, valves and/or reducers immediately adjacent to the meter inlet.

Don't - Install the meter near fast-acting valves. Fast-acting valves have the potential to create high magnitude hydraulic pressure spikes. These spikes can damage the internal components of the meter, resulting in inaccuracies or malfunction.

Don't - Allow unidirectional meters to be operated against the direction of the flow arrow. The standard flow meter is an unidirectional flow meter. The piston acts as a check valve to block flow in the reverse direction. This causes an excessive pressure differential, which can result in damage to internal meter components. The flow meter is also available in a modified design, which offers a reverse flow by-pass feature to accommodate bi-directional flow.

NOTE: *In-line meters with a reverse flow by-pass feature are available. Consult factory for details.*

Installing the Flow-Alert™

1. See Figure 3. Mount the meter so fluid is traveling in the direction of the flow arrow.
2. See Figure 4. Select a mounting location that is suitable for viewing and product service. To connect the flow meter into the piping system, place an open-ended wrench onto the flow meter wrench flats adjacent to the pipe connection being installed. **DO NOT** wrench on the opposite end of the flow meter or leakage may result.
3. See Figure 5. After installation, rotate meter by hand to view flow scale.




Figure 3. Flow Direction Arrows

Electrical Connections

MICRO SWITCH EQUIPPED MODELS

All meters (size 1/4" to 1-1/2") are offered in single (1) switch or double (2) switch models. The single switch model is equipped with a 34" length of 4-wire #18 AWG type SO jacketed cable. The double switch model is equipped with a 18" length 7-wire #16 AWG type SO jacketed cable.

MICRO SWITCH WIRE COLOR CODING

One Switch — 4-Wire Cable	
Red	Normally Closed (NC)
Black	Normally Open (NO)
White	Common
Green	Ground

Two Switch — 7-Wire Cable—Switch 1	
Red	Normally Closed (NC)
Black	Normally Open (NO)
White	Common

Two Switch — 7-Wire Cable—Switch 2	
Orange	Normally Closed (NC)
Blue	Normally Open (NO)
White/Black	Common
Green	Ground




Figure 4. Installing Meter




Figure 5. Rotating Meter

A 4-pin Brad Harrison® quick-disconnect plug is available upon special order.

4-Pin Connector used with SPDT Micro Switch	
Red	Normally Closed (NC)
Black	Normally Open (NO)
White	Common
Green	Ground

NOTE: If the factory supplied cable is removed for hard wiring the meter, switches must be connected with 0.187 x 0.020" insulated flag terminals designed for the appropriate wire gauge for the application.

REED SWITCH EQUIPPED MODELS

All meters (size 1/4" to 1-1/2") are offered in single (1) switch or double (2) switch models and come equipped with a 4-pin Hirschmann connector. All units are equipped with a 15' length of 4-wire #22 AWG type PVC jacketed cable.

4-Pin Connector used with SPST Reed Switch	
Red	Switch 1 Contact
Black	Switch 1 Contact
White	Optional Switch 2 Contact
Green	Optional Switch 2 Contact

DOUBLE BREAK SWITCH EQUIPPED MODELS


All meters (size 1/4" to 1-1/2") are offered with a single double break switch. Units are equipped with a 5-pin Brad Harrison® connector or can be furnished without the connector upon request.

5-Pin Connector used with Double Break Switch	
Pin 2 Orange	Normally Closed (NC)
Pin 4 Red	Normally Closed (NC)
Pin 1 Black	Normally Open (NO)
Pin 5 White	Normally Open (NO)
Pin 3 Green	Ground


ALL MODELS

The strain relief connection on the outside of the enclosure is water-tight. Be sure to consult local wiring codes before applying power. Some installations will require rigid conduit. By removing the black strain relief connection from the outside of the enclosure, a conduit connection is accessible.

Wiring Configurations



Wiring Configuration for Loads Within Flow-Alert Contact Ratings



Wiring Configuration for Loads that Exceed Flow-Alert Contact Ratings

IV. OPERATION

NOTE: Refer to the Appendix for application information and fluid charts.

Micro Switch & Double Break Switch Adjustment

1. Remove cover screws and front cover.

NOTE: On meters equipped with dual micro switches, the right-side is the decreasing flow switch; the left-side is the increasing flow switch.

2. Loosen the screws securing the switching roller and latching rollers to the guide bar. Turn each screw one full turn maximum.
3. All rollers are secured as a set to the spacer strip. Slide the entire roller set until pointer is at the desired setting.

NOTE: The spacer strip controls the maximum distance between rollers. This distance may be shortened when the switching setting is close to the end of the flow scale. Latching rollers may also be removed if the switching setting is close to the end of the flow scale.

4. Make sure roller brackets are flush against the guide bar. Tighten roller screws.
5. For dual switch models, repeat steps 1—4 for left-side switch setting.
6. Install the cover gasket and front cover and secure with screws. To properly seat the cover gasket, tighten cover screws in a criss-cross pattern as shown in Figure 7.




Figure 6. Snap Switch & Double Break Switch Adjustment




Figure 7. Cover Screw Tightening Sequence

Reed Switch Adjustment – 1/4" Models

1. Loosen the screw securing the switch assembly (Figure 8).
2. Slide the switch assembly until the arrow pointers on the switch band are aligned with the desired flow rate indicated on the scale.
3. Tighten the screw.

Reed Switch Adjustment – 1/4" to 1-1/2" Models

1. Remove cover screws and front cover.
2. Loosen the screw securing the switch assembly (Figure 9).

NOTE: On meters equipped with dual switches, the right-side is the decreasing flow switch; the left-side is the increasing flow switch.

3. Slide the switch assembly until the arrow pointer aligns with the desired flow rate indicated on the scale.
4. Tighten the screw.
5. For dual switch models, repeat steps 1—4 for left-side switch setting.
6. Install the front cover and gasket. To properly seat the cover gasket, tighten cover screws in a criss-cross pattern as shown in Figure 7 on page 6.





Figure 8. Reed Switch Adjustment - 1/4" Models



**Figure 9. Reed Switch Adjustment
1/4" - 1 1/2" Models
(Dual Switch Shown)**

V. MAINTENANCE

WARNING

Disconnect electrical power before removing meter cover. Failure to follow these instructions could result in serious personal injury or death and/or damage to the equipment.

Switch Replacement

MICRO SWITCH & DOUBLE BREAK SWITCH (FIGURE 10 ON PAGE 9)

1. Disconnect cable connection to the meter.
 2. Remove screws securing cover and remove cover.
 3. Note the positions of the colored wire connections on the switch. Disconnect the wires from the switch.
 4. Remove the two mounting bracket screws at the bottom of the meter.
 5. Remove mounting bracket/switch assembly from the meter. Remove the two screws securing switch to mounting bracket.
 6. Install new switch to mounting bracket using screws removed in step 5.
 7. Install wires to terminals on switch as marked in step 3.
 8. Install mounting bracket/switch assembly to meter using screws removed in step 4.
 9. Install the front cover and gasket. To properly seat the cover gasket, tighten cover screws in a criss-cross pattern as shown in Figure 7 on page 6.
4. Remove the screws securing the two mounting brackets and remove the brackets.
 5. Loosen the two slide bracket screws.
 6. Remove the switch mounting screw and remove mounting block/switch assembly from slide bracket.
 7. Remove the two mounting screws securing switch to mounting block and pointer. Make note of switch position.
 8. Install new switch to mounting block and pointer using screws removed in step 7.
 9. Remove the strain relief.
 10. Install mounting block/switch assembly to slide bracket using screw removed in step 6.
 11. Tighten the slide bracket screws.
 12. Install strain relief.
 13. Install mounting brackets to scale using scale mounting screws. Do not fully tighten yet.
 14. Secure mounting brackets using screws removed in step 4.
 15. Tighten screws installed in step 10.
 16. Solder Hirschmann connector to new switch wires.

NOTE: For 1/4", 1/2", 3/4" and 1" units, wire should be cut to 5" length. For 1 1/4" and 1 1/2" units, wire should be cut to 10" length.

17. Install the front cover and gasket. To properly seat the cover gasket, tighten cover screws in a criss-cross pattern as shown in Figure 7 on page 6.

REED SWITCH (FIGURE 11 ON PAGE 9)

1. Disconnect the Hirschmann connector and remove connector from wires.
2. Remove screws securing cover and remove cover.
3. Remove the two scale mounting screws.

Cartridge Cleaning (Figure 12 on page 10)

1. Disconnect the meter cable.
2. Remove the meter from the line. Remove excess piping from meter.

⚠ WARNING

Before attempting to remove the meter from the line, check the system to confirm that line pressure has been reduced to zero PSI. Failure to follow these instructions could result in serious personal injury or death and/or damage to the equipment.

NOTE: It is not necessary to remove the aluminum housing from the meter to remove it from the line.

3. Thoroughly wipe off the entire meter surface using mild detergent or isopropyl alcohol.

⚠ CAUTION

Do not use aromatic hydrocarbons, halogenated hydrocarbons, ketones or ester based fluids on polycarbonate lens. Failure to follow these instructions could result in damage to the meter.

4. Remove the inlet end fitting, retaining spring, and metering cone/spider plate assembly from the cartridge.
5. Gently push the cartridge assembly towards the outlet port while holding magnetic indicator assembly in place.
6. The cartridge internal parts are secured with a retaining ring. Remove the retaining ring and the remaining internal parts from the cartridge.

NOTE: If internal parts do not slide freely from cartridge, use a wooden dowel inserted into the outlet port of the meter to push parts out.

7. Place all parts on a clean work surface. Clean and inspect all parts. Replace any that appear worn or damaged.

Check inlet port O-ring for damage and replace if required.

8. Reassemble spring, then piston/magnet assembly and retaining ring into cartridge.




Figure 10. Micro Switch & Double Break Switch Replacement




Figure 11. Reed Switch Replacement

9. Gently push cartridge assembly into housing while holding the magnetic flow indicator in position.
10. Install metering cone/spider plate assembly, retaining spring, and secure with inlet fitting.
11. Reinstall meter to the line. Reconnect electrical power.

Quick Re-Coupling

This piston-type variable area flow meter is inherently less sensitive to shock and vibration than other variable area designs. The unique magnetic coupling also eliminates the need for mechanical linkages that can wear or loosen over the functional life of the meter.

However, on occasion, a pressure spike or extreme flow surge can cause the piston to move at such rapid speed that it disconnects the piston (magnetic coupling) from the external magnetic indicator ring. If this occurs, use one of these procedures to re-couple the piston magnet and the external indicator ring:

- If the system permits, simply change flow rate from "no flow" to "full flow" allowing the moving piston to magnetically re-couple to the indicator ring.
- Remove cover and manually re-attach external flow indicator to internal magnet/piston assembly.
- For rigorous cyclical applications where de-coupling may occur frequently, consult the technical services staff for further recommendations.

VI. APPENDIX

Application Information – Liquid

Viscosity Effect (SUS/cSt)

The design utilizes a precision machined, sharp-edged orifice and biasing calibration spring that assures operating stability and accuracy over the wide viscosity range common to many fluids. Generally, high flow models of each meter size provide good accuracy over a viscosity range of 40 to 500 SUS (4.2 to 109 cSt).




Figure 12. Cartridge Components

Density Effect (specific gravity)

Any fluid density change from stated standards has a proportional effect on meter accuracy. Special scales can be supplied if actual specific gravity decreases accuracy beyond application limits. Corrections for more or less dense fluids can be made to standard scales using the following correction factor:


$$\frac{1.0}{\sqrt{\text{Specific Gravity}}} \text{ for water/water-based meters}$$

$$\frac{0.876}{\sqrt{\text{Specific Gravity}}} \text{ for petroleum-based meters.}$$

Application Information – Pneumatic

NOTE: Pressure and temperature readings must be taken at the flow meter inlet to ensure accurate correction factors.

The pneumatic flow meter is offered with a standard graduated dual scale, calibrated for air in standard cubic feet per minute (scfm) at 1.0 s.g. (70 °F @ 100 psi), and liters per second (lps) at 1.0 s.g. (21 °C @ 6.9 bar).



DETERMINE FLOW RATES USING DIFFERENT PRESSURES & TEMPERATURES

$$\text{SCFM (Actual)} = \frac{\text{SCFM (Indicated)}}{f_1 \times f_2 \times f_3}$$

f_1 = conversion factor for inlet pressure
 f_2 = conversion factor for temperature
 f_3 = conversion factor for specific gravity

TABLE 1 PRESSURE CORRECTION FACTOR (F₁)

Operating Pressure (psig)										
psig	25	50	75	100	125	150	175	200	225	250
f ₁	1.700	1.331	1.131	1.00	.902	.835	.778	.731	.692	.658

$$f_1 = \sqrt{\frac{114.7}{14.7 + \text{psig}}}$$

TABLE 2 TEMPERATURE CORRECTION FACTOR (F₂)

°F	10	30	50	70	90	110	130	150	170	190
f ₂	.942	.962	.981	1.00	1.018	1.037	1.055	1.072	1.090	1.107

$$f_2 = \sqrt{\frac{460 + ^\circ\text{F}}{530}}$$

TABLE 3 SPECIFIC GRAVITY CORRECTION FACTOR (F₃)

$$f_3 = \sqrt{\text{Specific Gravity}}$$





FLUID SELECTION CHART

Air/Gas	Specific Gravity	Correction Factor Std. Scale	Aluminum	Brass	T316 SST	T303 SST	Viton®	EPR	Polycarbonate	Nylon	Pyrex®
Air	1.0	1.000	R	R	R	R	R	R	R	R	R
Argon(A)	1.38	1.175	R	R	R	R	R	R	R	R	R
Carbon Dioxide(CO ₂)	1.53	1.237	R	R	R	R	R	R	R	R	R
Freon 11 (CCl ₃ F)	4.92	2.218	R	R	R	R	R	R	R	R	R
Freon 12 (CCl ₂ F)	4.26	2.060	R	R	R	R	R	R	R	R	R
Helium(HE)	0.14	0.374	R	R	R	R	R	R	R	R	R
Hydrogen (H ₂)	0.07	0.265	R	R	R	R	R	R	R	R	R
Natural Gas	0.60	0.775	C	C	R	C	N	C	R	R	R
Nitrogen (N ₂)	0.97	0.985	C	C	R	R	R	R	C	R	R
Oxygen (O ₂)	1.10	1.049	R	R	R	R	R	R	R	R	R
Propane (C ₃ H ₈)	1.57	1.253	R	R	R	R	R	N	N	R	R




R = Recommended
 N = Not recommended
 C = Consult Factory

Flow vs. Pressure Drop





Water-based Fluids







Water-based Fluids (continued)










Water










Caustic and Corrosive Liquids







Petroleum Fluids







Phosphate Ester







A.P.I. Oil



Air / Caustic and Corrosive Gases



Air / Compressed Gases



LIMITED WARRANTY and DISCLAIMER

Hedland, Division of Racine Federated Inc. warrants to the end purchaser, for a period of one year from the date of shipment from the factory, that all flow meters manufactured by it are free from defects in materials and workmanship. This warranty does not cover products that have been damaged due to misapplication, abuse, lack of maintenance, or improper installation. Hedland's obligation under this warranty is limited to the repair or replacement of a defective product, at no charge to the end purchaser, if the product is inspected by Hedland and found to be defective. Repair or replacement is at Hedland's discretion. A returned goods authorization number must be obtained from Hedland before any product may be returned for warranty repair or replacement. The product must be thoroughly cleaned and any process chemicals removed before it will be accepted for return.

The purchaser must determine the applicability of the product for its desired use and assumes all risks in connection therewith. Hedland assumes no responsibility or liability for any omissions or errors in connection with the use of its products. Hedland will under no circumstances be liable for any incidental, consequential, contingent or special damages or loss to any person or property arising out of the failure of any product, component or accessory.

All expressed or implied warranties, including **the implied warranty of merchantability and the implied warranty of fitness for a particular purpose or application are expressly disclaimed** and shall not apply to any products sold or services rendered by Hedland.

The above warranty supersedes and is in lieu of all other warranties, either expressed or implied and all other obligations or liabilities. No agent or representative has any authority to alter the terms of this warranty in any way.



8635 Washington Avenue, Racine, WI 53406-3738
Telephone 262-639-6770 or 1-800-HEDLAND
Fax 262-639-2267 or 1-800-CHK-FLOW
www.Hedland.com HedlandTechHelp@Racinefed.com
Materials & specifications are subject to change without notice.

Hedland is a registered trademark of Racine Federated Inc.
Flow-Alert is a trademark of Racine Federated Inc.
Teflon is a registered trademark of E.I. du Pont de Nemours and Company.
Pyrex is a registered trademark of Corning Glass Works Corporation.
Brad Harrison is a registered trademark of Woodhead Industries, Inc.